



Appendix A: Star Codes

The following table shows available star codes (short cuts) that you can use on your phone.

Star Code	Feature	MiNET	VVX	SIP
*51	Intercom	Intercom PMK Dial *51, phone prompts for extension	Intercom Softkey Dial *51EXT then send	Dial *51EXT then send
*67	Outgoing Call Privacy (OCP) (feature must be enabled)	OCP PMK Dial *67, then dial external number	OCP Softkey Dial *67XXXXX then send	Dial *67XXXXX then send
*94	Directed Call Pickup (DCP) (must be monitor secondary with answer permission)	DCP PMK Dial *94, phone prompts for extension	DCP Softkey Dial *94EXT then send	Dial *94EXT then send
*95	Park Call	Park/Retrieve PMK *95 not supported	Park softkey Blind transfer (REFER) to *95X where X=park location	Polycom SPIP: use park softkey, enter park location Blind transfer (REFER) to *95X where X=park location
*96	Retrieve Call	Park/Retrieve PMK *96 not supported	During off-hook, press "Pickup" softkey, then "Retrieve" and enter park location Dial *96X where X=park location	Polycom SPIP: During off-hook, press "Pickup" softkey, then "Retrieve" and enter park location Dial *96X where X=park location
*97	Site Page	Page PMK Dial *97	Page Softkey *97 not supported	Page Softkey *97 not supported
*98	Voicemail Retrieval	Voicemail hardkey Voicemail PMK Dial *98	Voicemail soft/hardkey Dial *98 SIP URI="voicemail"	Polycom SPIP: Voicemail soft/hardkey Dial *98 SIP URI="voicemail"
*99	Transfer to VM	Transfer softkey, follow prompts	Transfer to *99EXT	Transfer to *99EXT
*00	Activate/Logout	Dial *00 follow prompts	n/a	n/a